

**Die aktuelle Ersatzteilreferenzliste  
des Classic Lieferprogramms für  
DVD/CD Laserprodukte....**

**CDM = Laser Mechanismus**  
**LPU = Single Laser Pick-Up**  
**MPU = Mini Disc Pick-Up**  
**CDF = Flachbandkabel**

**The latest Cross-Reference-List for  
the Classic range of DVD/CD laser  
products ....**

**CDM = Laser Mechanism**  
**LPU = Single Laser Pick-Up**  
**MPU = Mini Disc Pick-Up**  
**CDF = Flat Cable**



Original Part No.	Brand	Classic Part No.
101 177 40	THOMSON	LPU31003
134-0-4009-04300	SANYO	LPU31054
141730311	AIWA	LPU31113
1-575-001-11	SONY	CDF31010
1-575-003-11	SONY	CDF31068
163000034001	ALCO	CDM31270
163-000216-000	GRUNDIG	CDM31265
1-777-955-11	SONY	CDF31101
24804019	SANYO	LPU31058
2892271	UNIVERSUM	CDM31279
3041R-0041 A	LG	LPU31262
3104 147 00271	OTTO-VERSAND	CDM31183
3104 147 00271	PHILIPS	CDM31183
3104 147 00301	PHILIPS	CDM31080
3305 022 20201	PHILIPS	CDM31080
350 612 70	THOMSON	LPU31061
350 650 00	THOMSON	LPU31001
357 207 30	THOMSON	CDM31270
411351B	SONY	LPU31003
4822 691 10615	GRUNDIG	CDM31080
4822 691 10615	PHILIPS	CDM31080
4822 691 10772	PHILIPS	CDM31185
4822 691 30258	PHILIPS	LPU31003
4822 691 30282	PHILIPS	LPU31001
4822 691 30354	OTTO-VERSAND	CDM31183

Original Part No.	Brand	Classic Part No.
482269130354	PHILIPS	CDM31183
559318026	TELEFUNKEN	LPU31003
559318026	THOMSON	LPU31003
614 002 1417	SANYO	LPU31054
614 258 6640	SANYO	LPU31003
620 062 6170	SANYO	LPU31054
620 062 6200	SANYO	LPU31054
620 201 5774	SANYO	LPU31054
620 217 9988	SANYO	LPU31054
620 219 2468	SANYO	LPU31054
645 005 5966	SANYO	LPU31057
645 006 7983	SANYO	LPU31058
75952-030.55	GRUNDIG	CDM31080
75955-104.4200	GRUNDIG	CDM31272
8 633 811 548	BLAUPUNKT	LPU31036
84-ZG1-614-110	AIWA	CDF31095
87A90956010	AIWA	MPU31199
8-848-062-01	SONY	LPU31001
884813701	SANYO	LPU31003
8-848-233-11	SONY	LPU31002
8-848-233-11	SONY	LPU31002R
884831311	SONY	LPU31001
884838701	SONY	LPU31061
884841509	SONY	LPU31061
92 LHPC 1 LXASY (7/8)	SHARP	LPU31181
92 LHPC 1 MASY	SHARP	LPU31052
92 LHPC 1 MASY (5/8)	SHARP	LPU31052
92 LHPC 1 MX (7/8)	SHARP	LPU31182
92 LHPC 1 UASY	SHARP	LPU31014
928 TX 0417	SABA	LPU31001
92LHPC1CCASY	SHARP	LPU31041
9305 022 20111	PHILIPS	CDM31080
9305 022 20212	PHILIPS	CDM31080
9305 022 20219	PHILIPS	CDM31080
9305 022 30101	PHILIPS	CDM31185
9305 022 30103	PHILIPS	CDM31185
9305 022 30107	PHILIPS	CDM31185
9305 023 61001	PHILIPS	LPU31229
988 481 37119	SANYO	LPU31003
98848137119	AIWA	LPU31003
9-885-037-37	SONY	LPU31243
A-4411-949-A	SONY	LPU31067
A-4-713-410 A	SONY	CDM31260
A6061908A	SONY	CDM31268
AH30-00003A	SAMSUNG	LPU31169
AH30-00008A	SAMSUNG	LPU31150
AJ30-20001F	SAMSUNG	LPU31074
AK97-00166A	SAMSUNG	LPU31243
AK97-00166B	SAMSUNG	LPU31256
AK97-00168A	SAMSUNG	LPU31243
AK97-00168B	SAMSUNG	LPU31256
AK97-00943A	SAMSUNG	LPU31263
APU0201	TELESTAR	LPU31244
CD 94 V 5	SANYO	LPU31173
CDM-12.1	GRUNDIG	CDM31080
CDM-12.1/05	PHILIPS	CDM31080
CDM12.4	OTTO-VERSAND	CDM31183
CDM-12.4	PHILIPS	CDM31183
CDM-12.4/01	PHILIPS	CDM31183

— für die Suche nach Geräten benutzen Sie bitte unsere website —  
— for searching with models please use our website —

für weitere Informationen/ for more details: [www.classic-serviceparts.com](http://www.classic-serviceparts.com)

Original Part No.	Brand	Classic Part No.	Original Part No.	Brand	Classic Part No.
CDM-12.4/05	PHILIPS	CDM31183	KSS-210ARP	SONY	LPU31001
CMS-S11MG6	GRUNDIG	CDM31266	KSS-210B	AIWA	LPU31003
CMS-S11MG6U	SAMSUNG	CDM31266	KSS-210B	PHILIPS	LPU31003
CMS-S21MG6	GRUNDIG	CDM31265	KSS-210B	SANYO	LPU31003
CMS-S21MG6	SAMSUNG	CDM31265	KSS-210B	SONY	LPU31003
DA 11	SANYO	LPU31174	KSS-210B	THOMSON	LPU31003
DA 11 T 3 C	SANYO	LPU31175	KSS-212A	AIWA	LPU31001
DA11B3V	CLATRONIC	CDM31284	KSS-212A	SONY	LPU31001
DA11B3V	SANYO	CDM31284	KSS-212B	SONY	LPU31003
DBU-1	SONY	CDM31260	KSS-212B	THOMSON	LPU31003
DP-C120B	AKAI	LPU31105	KSS-213 DRP	SONY	LPU31103
DP-C120B	DAEWOO	LPU31105	KSS-213B	SONY	LPU31061
FLC-01	ALCO	CDM31270	KSS-213B	THOMSON	LPU31061
FLC-01	THOMSON	CDM31270	KSS-213BA	SONY	LPU31061
H8112AF	SHARP	LPU31049	KSS-213BRP	SONY	LPU31061
H8136AF	KENWOOD	LPU31014	KSS-213C	DENON	LPU31105
H8136AF	SHARP	LPU31014	KSS-213C	SONY	LPU31105
H8147AF	SHARP	LPU31041	KSS-213D	SONY	LPU31103
H8151AF	JVC	LPU31052	KSS-213F	AIWA	LPU31113
H8151AF	QUELLE	LPU31052	KSS-213F	SONY	LPU31113
H8151AF (5/8)	SHARP	LPU31052	KSS-240A	SONY	LPU31002
H8151AS (5/8)	SHARP	LPU31052	KSS-240A	SONY	LPU31002R
H8164AF	SHARP	LPU31182	KSS-240A(RP)	SONY	LPU31002
H8175AF	SHARP	MPU31187	KSS-240A(RP)	SONY	LPU31002R
HD 151	SHARP	LPU31052	KSS-313A	SONY	LPU31207
HOP-1200 S	UNIVERSUM	LPU31259	KSS-320B	BLAUPUNKT	LPU31036
HOP-1200 W	TELESTAR	LPU31273	KSS-320B	SONY	LPU31036
HPC-1CC	SHARP	LPU31041	KSS-333A	SONY	LPU31001
HPC-1L	SHARP	LPU31180	KSS-390A	SONY	LPU31067
HPC-1LX (7/8)	SHARP	LPU31181	KSS-540A	SONY	LPU31119
HPC-1MX	SHARP	LPU31182	KSS-582A	SONY	LPU31201
HPC-3LX	SHARP	LPU31225	KSS-610A	SONY	LPU31202
KCP-1H	KENWOOD	LPU31203	KSS-710A	SONY	LPU31152
KHM-290AAA	SONY	CDM31268	M8AZKJ92070	AIWA	CDM31240
KHM-310AAA	SONY	CDM31276	M8AZKJ93070	AIWA	CDM31240
KHS-400 B	SONY	LPU31228	OPC-A15-1	CLATRONIC	LPU31282
KHS-400 C	SONY	LPU31228	OPC-A15-1	PHILIPS	LPU31282
KMS-280A	AIWA	MPU31199	OPTIMA-7	JVC	LPU31161
KMS-280A	SONY	MPU31199	OPTIMA-7 A	JVC	LPU31161
KRS-200A	SONY	LPU31277	OPTIMA-7 B	JVC	LPU31161
KSM-213CCM	SONY	CDM31155	OPTIMA-710 A	JVC	LPU31152
KSM-330A	SONY	CDM31154	OPTIMA-720	JVC	LPU31163
KSM-331AAN	SONY	CDM31192	OPTIMA-720 A1	JVC	LPU31163
KSM-440ADM	SONY	CDM31115	PEA 1291	PIONEER	LPU31205
KSM-440AEM	SONY	CDM31156	PVR-202T	LG	LPU31262
KSM-440BAM	SONY	CDM31194	PVR-202T	MITSUMI	LPU31262
KSM-542AAA	SONY	CDM31200	PVR-802W	LG	LPU31269
KSM-780A	SONY	CDM31230	PVR-802W	MITSUMI	LPU31269
KSM-780AAA	SONY	CDM31230	PVR-802W	SONY	LPU31269
KSS-150A	AIWA	LPU31001	PWY 1009	PIONEER	LPU31017
KSS-150A	SABA	LPU31001	QYCD01B	CLATRONIC	CDM31283
KSS-150A	SONY	LPU31001	RAE 0130 Z	PANASONIC	LPU31212
KSS-150B	SONY	LPU31001	RAE 0150 Z	PANASONIC	CDM31165
KSS-150B	THOMSON	LPU31001	RAE 0152 Z	PANASONIC	LPU31164
KSS-152A	SONY	LPU31000	RAE 0152 Z	TECHNICS	LPU31164
KSS-152A	TOSHIBA	LPU31000	RAE 0152 ZZ	TECHNICS	LPU31164
KSS-210A	AIWA	LPU31001	RAE0153Z-3S	PANASONIC	CDM31267
KSS-210A	PHILIPS	LPU31001	RCTRH8112AFZZ	SHARP	LPU31049
KSS-210A	SONY	LPU31001	RCTRH8136AFOO	SHARP	LPU31014

— für die Suche nach Geräten benutzen Sie bitte unsere website —  
 — for searching with models please use our website —

für weitere Informationen/ for more details: [www.classic-serviceparts.com](http://www.classic-serviceparts.com)



Original Part No.	Brand	Classic Part No.
RCTRH8136AFZZ	KENWOOD	LPU31014
RCTRH8136AFZZ	SHARP	LPU31014
RCTRH8147AFZZ	SHARP	LPU31041
RCTRH8148	KENWOOD	LPU31203
RCTRH8148AFZZ	SHARP	LPU31203
RCTRH8151AFZZ	JVC	LPU31052
RCTRH8151AFZZ	SHARP	LPU31052
RCTRH8164AFZZ	SHARP	LPU31182
RCTRH8175AFZZ	SHARP	MPU31187
SF 91	WATSON	LPU31054
SF-88	SANYO	LPU31054
SF-91	SANYO	LPU31054
SF-91 (5/8)	SANYO	LPU31057
SF-91 (6/5)	SANYO	LPU31072
SF-HD 6	SANYO	LPU31258
SF-HD 60	SANYO	CDM31271
SF-HD3	AIWA	CDM31240
SF-HD3	FISHER	CDM31240
SF-HD3	SANYO	CDM31240
SF-HD62	SANYO	LPU31274
SF-HD65	SANYO	CDM31278
SF-P1 (6/6)	SANYO	LPU31054
SF-P100	SANYO	LPU31058
SF-P101 (16)	SANYO	LPU31175
SF-P101 (5/8)	SANYO	LPU31173
SF-P101N	SHARP	LPU31174
SF-P101N (15)	PHILIPS	LPU31174
SF-P101N (15)	SANYO	LPU31174
SH1166170001	KENWOOD	LPU31014
SOH-90T4	SAMSUNG	LPU31074
SOH-90T4N	SAMSUNG	LPU31074
SOH-A1	SAMSUNG	LPU31047
SOH-A1U	SAMSUNG	LPU31047
SOH-AA	SAMSUNG	LPU31169
SOH-AAN (16PIN)	SAMSUNG	LPU31280
SOH-AAN (4C)	SAMSUNG	LPU31280
SOH-AAU	SAMSUNG	LPU31170
SOH-AAV	SAMSUNG	CDM31279
SOH-AAV	UNIVERSUM	CDM31279
SOH-AD	SAMSUNG	LPU31171
SOH-AD3	SAMSUNG	LPU31186
SOH-AD3U	SAMSUNG	LPU31186
SOH-ADU	SAMSUNG	LPU31171
SOH-AP/APU	SAMSUNG	LPU31116
SOH-D21U	SAMSUNG	LPU31221
SOH-DS2	SAMSUNG	LPU31222
SOH-DSS	SAMSUNG	LPU31243
SOH-DSSA	SAMSUNG	LPU31243
SOH-DSSA	SONY	LPU31243
SOH-DSSB	SAMSUNG	LPU31256
SOH-DSSB	SONY	LPU31256
SOH-DT2	SAMSUNG	LPU31263
SOH-DV1U	SAMSUNG	LPU31150
SOH-OT4	SONY	LPU31003
STSD-010SMT	GRUNDIG	CDM31266
T25-0019-05	KENWOOD	LPU31014
T25003208	KENWOOD	LPU31014
T25005025	SHARP	LPU31203
TACHS-MR	TOSHIBA	LPU31000

Original Part No.	Brand	Classic Part No.
TCP 11 TK 2	THOMSON	CDM31272
TCP 11 TK 2 X	GRUNDIG	CDM31272
TCP 11 TK 2 X	THOMSON	CDM31272
TCP 11 TK 2 XLF	THOMSON	CDM31272
TOPH-7833	TOSHIBA	LPU31000
VAL 3000	PHILIPS	LPU31229
VAM 1201 D	PHILIPS	CDM31080
VAM 1201/11	GRUNDIG	CDM31080
VAM 1201/11	PHILIPS	CDM31080
VAM 1202	PHILIPS	CDM31080
VAM 1202 D	PHILIPS	CDM31080
VAM 1202 J	PHILIPS	CDM31080
VAM 1202/12	PHILIPS	CDM31080
VAM 2201/01	PHILIPS	CDM31185
VAM 2201/03	PHILIPS	CDM31185
VAM 2201/07	PHILIPS	CDM31185



— für die Suche nach Geräten benutzen Sie bitte unsere website —  
— for searching with models please use our website —

für weitere Informationen/ for more details: [www.classic-serviceparts.com](http://www.classic-serviceparts.com)